

MODEL NO. 10.6000 Series Low-Profile ESL X-TRA Light with 10.3003 3-Output LED Flasher

INSTALLATION:

Select a location suitable for installation of the flasher and light. Take special care to ensure the wires do not obstruct the deployment of the airbag! Mark the location of the mounting holes for the flasher and light. Drill holes at these locations. Mount the flasher and light using the supplied hardware.

NOTE: This wiring diagram is for use with a 10.3003 flasher and 10.6000 Low-Profile ESL X-TRA Light Only!



