



Controller 11.1007 for Model 12.6207

Quad Flash 2-2



Quad Flash 3-3



Alternating 3-3




Random Flash


Double Flash 3-3




Double Flash 2-2



Left Arrow



Left Arrow - Double Flash




Center then Outer



Center Out



Right Arrow



Right Arrow - Double Flash

