

# Controller Model 11.1007 for Signal Stick Model 12.6209

## Random Flash



## Double Flash 2-2



## Double Flash 3-3



## Alternating 3-3




## Center Out




## Center then Outer




## Left Arrow




## Left Arrow - Double Flash




## Quad Flash 2-2



## Right Arrow



## Right Arrow - Double Flash



## Quad Flash 3-3

