

## \*IMPORTANT NOTE: WARRANTY DOES NOT COVER WATER DAMAGE\*

When mounting speaker, it is important to locate the drain hole at the bottom to allow for adequate drainage. If necessary, remove the driver from the bracket and rotate it. Failure to do so may cause water damage, resulting in speaker failure.



PRODUCTS COMPANY804 East Hwy 248Cassville, MO 65625U.S. and Canada Toll Free NumbersPhone: 800-641-4098 FAX: 800-526-1240E-mail: sales@able2products.comWEB: www.able2products.com