



# Model 03.W3010.RANDOM Sequential Flasher

**General Information:** Input voltage - +12v  
Max. Amp Draw - 4 amps per output  
Fuse - Maximum 10 amps

## Installation:

Before installation of this flasher, disconnect the battery from electrical system. When selecting a location to mount the flasher, keep in mind that the life of any electronic device is directly dependent on the temperature in which it is operated - the cooler the unit, the longer the life. Select a mounting location that is away from sources of extreme heat.

