




MODEL NO. 01.0550 Permanent-Mount Single Rotating Light



INSTALLATION INSTRUCTIONS:

1. Remove four (4) screws holding the lens on the base.
2. Locate four (4) holes in the base which have **bevelled edge** (countersink).
3. Place base in desired mounting location. Using the base as a template mark holes. Remove base and drill holes. Fasten using the four (4) screws and lock-nuts provided.
4. Replace the lens using screws provided.
5. Connect the Black wire to - Ground.
6. Connect the Red wire to Positive +12 volts through a switch, fused at 8amps.



PRODUCTS COMPANY 804 East Hwy 248 Cassville, MO 65625
U.S. and Canada Toll Free Numbers Phone: 800-641-4098 FAX: 800-526-1240
E-mail: sales@able2products.com WEB: www.able2products.com